



DECK CLEANER

CLEANER & BRIGHTENER

Product description	DECK CLEANER is a powerful one - step cleaner and brightener that removes ground in and surface dirt while restoring a bright, vibrant look to fiberglass and weather-beaten marine wood such as Teak and Mahogany. Unlike bleach or chlorine based cleaners it will not damage the wood fibers.
Properties	<ul style="list-style-type: none">• Lightens and restores color to all greyed weathered marine wood without bleaching.• Fast acting, restores greyed weathered wood to its natural color within 20 minutes.• Excellent degreaser for tropical hardwoods prior to applying DEKS OLJE® D.1* saturator.• Removes all traces of weathering attributed to mold, mildew, pollution...• Restores luster to plastics dulled by weathering and UV rays.• Removes rust stains.• Neutralizes the action of MARINE STRIP*.• Safe to use - harmless to plants and shrubs.• Does not contain solvents or bleach - rinse with water.
Basic uses	<ul style="list-style-type: none">• For exterior use only.• For marine wood - Teak, Mahogany.• For fiberglass - Deck.• Horizontal or Vertical surfaces.
Technical data	<p>Viscosity: Thick (concentrate).</p> <p>Specific Gravity: N/A.</p> <p>Physical State: Liquid.</p> <p>Flammability: N/A.</p> <p>Combustibility: N/A.</p> <p>Flash Point: N/A.</p> <p>Shelf Life: 18 months unopened.</p> <p>Container Size: 1.06 U.S. quart, 0.66 U.S. gallon, 3.96 U.S. gallon.</p> <p>Appearance & odor: Blue, fresh soap odor.</p> <p>VOC: N/A.</p>
Application tools	<ul style="list-style-type: none">• Soft brush or broom - do not use a wire brush.• Stiff bristle/nylon brush or broom.• Powerwasher.• Wear chemical resistant gloves, safety goggles and protective clothing.
Good application practice	<ul style="list-style-type: none">• Shake container thoroughly before use.• Cover areas you want to protect.• Apply between 41°F and 95°F. Do not apply on a hot surface.• Do not allow DECK CLEANER to dry on surface. If drying occurs dampen with mist application of water.• If cleaning vertical wood, work from bottom to top to avoid streaking.

Application

CAUTION: Surfaces are slippery when wet. Use caution when walking on wet surfaces during application.

For Marine Wood:

- Wet surface with fresh, clean water.
- Apply DECK CLEANER with a soft brush or roller (long pile).
- Scrub surface with a stiff nylon/synthetic brush.
- Leave to stand for approx 10-20 minutes.
- Scrub surface while rinsing with water or use a pressure washer (max. 60 bar/870 psi).
- If required repeat procedure.
- Allow wood to dry 48 hours before applying a finish.

For Fiberglass:

- Wet the surface.
- Apply DECK CLEANER using a brush.
- Leave to work for 10 minutes.
- Rinse with large amounts of fresh clean water.

For Nail Stains:

- Clean and wet the surface.
- Apply DECK CLEANER to the entire surface over and around the nail stain.
- Do not rinse until the stain has disappeared.

Coverage

- 50.9 to 101.83 sq ft per U.S. quart.
- Actual coverage will vary depending on type, age and texture of surface.

Clean-up

- Soap and water.

After cleaning

- Protect and enhance the natural beauty of marine wood with DEKS OLJE® D.1* finish.

Storage

- Store unused portion in tightly closed plastic container.
- Keep from freezing.

General information

Every care is taken to ensure that the information provided in this technical data sheet is accurate. **OWATROL INTERNATIONAL** is unable to guarantee results as we have no control over the conditions under which our products are applied. For further advise and information please contact us on contact@deksolje.com.au.

The information above is correct at the date of issue.

Safety

Keep out of the reach of children.

MSDS available at www.deksolje.com.au

Issue date

December 2015.

* Same manufacturer.

OWATROL ASIA PACIFIC

'Huehn & Partners'

PO Box 227

Cannonvale QLD 4802 / AUSTRALIA

DECK CLEANER is a trademark



Find all our solutions:

www.deksolje.com.au

contact@deksolje.com.au